



For new walls or when the contractor neglected to install horizontal 2x4 blocks between plywood panels. See APA Technical Note #N370C, May 1997.

Sheetmetal Blocking