



- ① At vertical plywood joints, nail studs together with 12d commons 3" o.c. staggered, and nail plywood to studs with 8d commons 2" o.c. staggered.
- ② At all plywood edges, nail plywood to studs 2" o.c. staggered with 8d commons.
- ③ In field, drop chalk line down center of studs and nail plywood to framing with 8d commons 12" o.c.
- ④ Along upper topplate, nail plywood with 8d commons 2" o.c. staggered. Nailing no required on lower topplate.

Nailing Plywood