



- ① Nail studs together at plywood splice (thru new stud into old stud) with 12d commons placed 3 inches o.c. staggered. Nail new studs to mudsill and topplates with three 8-d common toenails.
- ② Nail holddown studs together (thru new stud into old stud) with 12d commons 3 inches o.c. staggered.

## Shearwall Framing Nailing