



Lag Bolts - Front View

Shear transfer ties using 3/8" by 7" lag bolts when sheetrock prevents use of framing anchors