

Used when no topplate is present and distance between end joist and first joist makes installing a topplate impossible.