



New Construction  
missing topplate, plywood to next joist

Used when end joist is difficult to access or distance between end joist and first joist makes installing a topplate impossible.